

A

B

C


D


A

B


C

D






PFC HV start-up circuit (required for flyback controller that does not support additional Vdd load)



## PFC ultra low power standby oscillator



### Standby and start-up comparator

